

## Renovates, cleans and buffs

STEP 1 - RED Use this pad to remove old and worn surfaces, leaving a matt finish	
STEP 2 - BLUE Use this pad to remove scratches, cracks and unevenness, leaving a matt finish	
STEP 3 - YELLOW A pad for daily cleaning which removes dirt and scratches, leaving a satin surface which is easy to keep clean	
STEP 4 - GREEN A pad for daily cleaning which removes dirt and scratches, leaving a glossy surface. Dry-buff using a high-speed machine for a high gloss finish, depending on floor type	

### Eco Brilliance Range

- Daily cleaning without detergents
- Buffs floors to the shine you want
- Renovates old and worn floors and restores shine
- Can be used wet or dry at speed of 150 to 1,800 rpm and offers a much smoother, cleaner cut than traditional pad